

# AQUARIUM POWER FILTER



POWER FILTER MODEL # SWF05PUG

## SETUP AND OPERATING INSTRUCTIONS WITH IMPORTANT SAFEGUARDS

Uses UL Approved Pump Motor  
120V 60 HZ .036A

For Interior Household Use Only

Children under the age of 13 should be supervised by an adult with the setup, maintenance and fish care

**SW PRODUCTS**®

www.sunnywaycn.com  
Item# SWF05PUG

# FILTER INSTALLATION

Read and follow equipment safety precautions instructions prior to installation

**1**

Place the base (sump portion) of the filter on the bottom of the tank and position it towards the back of the tank.

Side view of the base (sump)




**2**



Make sure the extension tube is securely attached to the filter cartridge housing.

**3**



(A) Insert and align the extension tube onto the manifold tube and push downwards.

B) Place aquarium gravel on the bottom of the tank only after installation of the filter base (sump).

C) Do not cover base (sump) entirely. Only use gravel or pebbles larger than 1/2inch diameter.

**4**

Press the mounting bracket of the cartridge holder down onto the frame of the tank. The extension tube will telescope downward to the appropriate height.



**5**

**IMPORTANT**  
For optimum flow output, the water level should be maintained at the recommended water level at all times.

Recommended water level  
1 inch from top of tank  
(see line to the right)

**DO NOT RUN FILTER MOTOR DRY**  
Always maintain recommended water levels



**6**

1) To adjust filter flow to preferred output level, unplug power filter from electrical receptacle. Remove power filter from tank and turn upside down.

2) Move selector switch to the left to reduce flow output and to the right to increase flow output.

3) Reassemble filter, place back into tank and insert filter's power cord plug back into the electrical receptacle.



**IMPORTANT**

- **Do Not** use sand in your aquarium as this will clog the power filter’s intake. For best results use only gravel or pebbles in excess of 1/2 inch diameter.
- Filter cartridge should be replaced every three to four weeks or if heavily soiled and filter’s water flow becomes diminished.
- To change cartridge, unplug internal power filter to stop water flow, remove soiled cartridge and discard.
- Briefly rinse new cartridge under running tap water.
- Place new cartridge into filter cartridge housing and insert filter’s electrical plug into electrical receptacle.
- Remove filter cartridge when medicating fish, as it can absorb most medications.
- When cleaning power filter always unplug power cord from electrical power. Do not use detergents or soap as residues can be harmful to your fish.



Replace filter cartridge every 3 to 4 weeks or when heavily soiled and reduced filter flow. This filter uses SW Products S size replacement cartridges (SWP10FC-60) sold through various online retailers.

**READ AND FOLLOW ALL SAFETY INSTRUCTIONS**

1. Do not operate this unit if it has a damaged cord or plug. The power cord cannot be replaced. Inspect the power cord insulation to be sure there are no cuts or exposed wire. If so, discard and order a new replacement pump.
2. Do not place aquarium on any good surface that can be damaged by water or where water can come in contact with other electrical appliances.
3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities without instruction of proper use by a person responsible for their safety. Children under 13 should be supervised to ensure that they do not play with the appliance.
4. To avoid the unit plug or receptacle from getting wet, position the tank and stand to one side of a wall mounted receptacle to prevent water from dripping onto it. A “Drip Loop” should be made as shown below. We also recommended using a GFCI outlet.



**Drip Loop**

Sunnyway Enterprises Inc. warrants this aquarium product to be free from defects in material and workmanship under normal use and service and according to the provisions as specified in the accompanying assembly and operating instructions, for a period of 1 year from date of purchase. This warranty does not cover and Sunnyway Enterprises Inc. is not liable for the cost of repair or replacement of parts which have been subject to misuse, negligence, accident, improper installation, damage during shipment or handling, normal deterioration due to wear and exposure or defects caused by unauthorized parts or modification. **UNDER NO CIRCUMSTANCES WILL SUNNYWAY ENTERPRISES INC. BE LIABLE FOR ACCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF PROPERTY OR EQUIPMENT.** Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you the legal rights, which vary from state to state.

WARRANTY HELP  
 REPLACEMENT PARTS  
 OR TECH SUPPORT  
 IF ANY COMPONENTS ARE  
 DAMAGED OR MISSING  
 DO NOT RETURN TO RETAILER  
 PLEASE CONTACT

**customerservice@sunnywaycn.com**

SW PRODUCTS®  
 Tustin, CA 92782 USA  
 Made in China

www.sunnywaycn.com